


EMOTION

2 AÑOS
de asistencia
GRATUITOS

Un software que crece contigo: diseñado para lograr un mayor nivel de personalización, **eMotion** es la licencia OMNIA VMS para la gestión simultánea de hasta 3 sistemas y el soporte para un número ilimitado de usuarios conectados al mismo tiempo.


eMotion es escalable y expandible, perfecto para administrar sistemas pequeños y medianos. Simple e intuitivo, se puede enriquecer en cualquier momento para administrar e integrar otros dispositivos de seguridad, como control de acceso, anti-intrusión o lectura de matrículas.




Visión completa
para estructuras
de tamaño medio



Gestión de 3 sistemas
con cámaras y
usuarios ilimitados



Ampliable con
plug-in opcionales



EMOTION

CARACTERÍSTICAS PRINCIPALES

Gestión

La gestión del software se puede realizar de forma local y remota en todos los PC y dispositivos móviles que utilicen nuestro cliente OMNIA, desde dispositivos fijos y móviles.

Análisis de video y Privacidad

eMotion está equipado con una función básica de Violated Area, adecuada para entornos interiores y estériles. Para escenarios más avanzados, eMotion integra análisis de borde de terceros. Además, gracias al algoritmo patentado de enmascaramiento de privacidad, las áreas borrosas también se pueden eliminar del video grabado.

Mapas

Con los Mapas de Arteco que emplea la localización de los dispositivos instalados, es posible obtener una verificación rápida de los eventos y el área monitoreada.

Control Total

eMotion permite la centralización de diferentes sistemas, incluidos los de terceros, para garantizar una experiencia de control total para los responsables de seguridad.

Opcionales

Arteco Everywhere - Contact ID - LPR - Open Connector – Security Connector Videowall – Access Control Connector




REQUISITOS DE SISTEMA

Hardware

MINIMUM REQUIREMENTS	SUGGESTED REQUIREMENTS
CPU Desktop: Intel® Core i3® 7th generation o superior	CPU Desktop: Intel® Core i5® 9th generation o superior
CPU Server: Intel® Xeon® Bronze series o superior	CPU Server: Intel® Xeon® Silver series o superior
RAM: 8 GB o superior	RAM: 16 GB o superior
LAN: 1x Gigabit Ethernet Network Interface Card	LAN: 1x Gigabit Ethernet Network Interface Card

64 bit OS Compatibility

Windows 11
Windows 10 Pro or Enterprise
Windows Server 2016
Windows Server 2019 (including Essentials version)
Windows Server 2022



EMOTION

COMPARACIÓN DEL SOFTWARE

	● standard	○ optional	– not available	Pure	eMotion	Active	Extreme
License Mix				–	○	○	○
Max Number of supported cameras per server				20	unlimited	unlimited	unlimited
Max Number of supported servers				1	3	unlimited	unlimited
Max Number of simultaneous connections (client, mobile, web)				5	unlimited	unlimited	unlimited
Max Number of users				unlimited	unlimited	unlimited	unlimited
Authentication with Microsoft Active Directory	●			●	●	●	●
Manage via Omnia Web client	●			●	●	●	●
PTZ Control (incl. presets&sequences)	●			●	●	●	●
Multi Camera Playback (simultaneous playback of more than one camera)	●			●	●	●	●
Instant Replay	●			●	●	●	●
Event Notification	●			●	●	●	●
Event Search	●			●	●	●	●
Substream Support (Live&Recording)	●			●	●	●	●
Audio IN (audio in support Live&Rec, Axis + Onvif)	●			●	●	●	●
Virtualization (upon request)	●			●	●	●	●
Streaming Recoder (hardware decoder @low-res)	–			●	●	●	●
Web Device (embedded browser)	–			●	●	●	●
External I/O + Input External State (receive and send HTTP/CGI scripts)	–			●	●	●	●
Record to network storage (NAS, SAN...)	–			●	●	●	●
Privacy Mask (blurred image, removable from recorded video by admin user)	–			●	●	●	●
Maps Supervisor	–			●	●	●	●
Customization of user right to access specific cameras (Camera Selection)	–			●	●	●	●
Customization of user role rights (User Policies)	–			●	●	●	●
RTSP Streaming Output (recoding and sending of video streams from the VMS to third parties)	–			–	●	●	●
Edge Storage	–			–	–	●	●
Audio IN/OUT (Live&Rec audio in and out management, available for ONVIF devices only)	–			–	–	●	●
Videowall	–			○	○	○	●
Server Failover (Server Redundancy)	–			–	–	○	●
Storage Failover (min 2 disks required; in case of disk failure, the system redirect recordings on a pre-configured disk portion, SPARE)	–			–	–	–	●
Auxiliary Path (simultaneous recording on 2 storage paths)	–			–	–	–	●
<hr/>							
Analytics	Motion Detection Pure (on/off)			●	●	●	●
	Motion Detection eMotion (Basic filters)			–	●	●	●
	Smart Search			–	●	●	●
	Motion Detection Active (Advanced filters)			–	–	●	●
<hr/>							
Plug In	Arteco Everywhere Integration			●	●	●	●
	VCA light			–	–	○	○
	VCA with smart search			–	–	–	○
	LPR Server			–	○	○	○
	LPR - Support for LPR native cameras (Tattile, Selea,...)			–	○	○	○
	LPR - Support for Hikvision LPR and Targa System cameras (requires Arteco Gateway)			–	○	○	○
	LPR - Hanwha Wisenet App (also available as stand alone)			–	○	○	○
	Open Connector			–	●	●	●
	Security Connector			–	○	○	○
	Access Control Connector			–	○	○	○